


Processing Guidelines NP HS-1276 Hot Stamp Machine

Hot Stamping Instructions:

- Cut the foil to a size that covers the raised elements.
 It is not necessary to be exact, just don't be short.
- Turn on the heating elements and set the temperature for around 180 degrees Celsius. Allow 15:00 minutes to preheat.
- Place the sign on the work table of the hot stamp unit.
- Place the foil down over the raised copy (the dull side of the foil is the face; you will see the true color through the back of the film carrier).
- Push the work table back into the machine directly under the heated silicone pad.
- Bring the hated silicone pad down onto the foil and sign with minimal pressure for approximately 1 second, or until just after pressure is applied. (Note: Required pressure will increase with larger copy areas)
- The thermal activated pigment that is transferred melts onto the sign face and the process is complete.



For large, multiple image areas, an additional soft pad may be placed underneath the sign panel before applying pressure with the heated silicone pad.

